

ROMP Party

What is it?

ROMP Party is a remote-controlled panty vibrator designed for on-the-go clitoral stimulation. With 7 intensity levels, this discreet treat easily snaps into place for kinky adventures in solo and partnered play.



Key Selling Messages

- **Portable Pleasure:** Discreet and quiet, the Party panty vibe sits comfortably in underwear for thrilling clitoral vibrations – whenever and wherever you like.
- **Remote Control:** Send those good vibrations to you or a partner, even in public – with a subtle touch of the remote, you'll be a smooth operator.
- **Comfortable Fit:** Body-safe silicone feels good on skin while the vibe is held in place with an unobtrusive magnetic clip for effortless wear.
- **Waterproof & Rechargeable:** Get it wet & wild – this vibe is IPX7 waterproof. Simply recharge between uses and this toy will be ready to go when you are.

Only you are invited...

How to play

1. Simply place ROMP Party in your panties and secure it in place by attaching the magnet to the outside.
2. Hold the power button on the toy for 3 secs to turn ROMP Party on.
3. Use the (+) and (-) buttons on the remote to cycle through ROMP Kiss's 7 intensity levels. The remote works up to 5 meters in distance from the toy.
4. Hold the power button on the toy for 3 secs to turn ROMP Party off.

Product features

- 7 intensity levels
- Powerful vibrations
- Whisper quiet
- Remote control
- 10 meters range
- Body-safe silicone
- Travel friendly
- Comfortable fit
- IPX7 waterproof
- Magnetic charging
- Run time: Product: 60 min
- Remote: 5 hours
- Charge time: Product: 80 min
- Remote: 60 min


MSRP

EUR	USD	SEK	GBP	CHF	CAD	DKK
49,99	59,99	579	44,99	49,99	64,99	379
HKD	KRW	SGD	JPY	AUD	NTD	
400	75.000	70	7.500	79	1.600	

ROMP Party

How to sell & demo

1. Start the demo by telling your audience that ROMP Party is a panty vibrator designed for quiet yet powerful vibrations – making it perfect for public play. Highlight how Party snaps easily into place with the magnetic clip for a comfortable, secure fit.
2. Note that ROMP Party comes with a remote control for discreet and subtle play. Pocket ready, the remote control feature makes it less obvious than using an app-controlled screen. Plus, Party has high-quality features at an appealing price point: It offers 7 intensity levels, is rechargeable and waterproof (IPX7, meaning it can be fully immersed in water). ROMP Party is coated in ultra-hygienic, silky soft, body-safe silicone.
3. Demo ROMP Party by holding the power button for 3 seconds to turn on the clitoral stimulator. Showcase the remote by pressing the (+) and (-) buttons to cycle through ROMP Party's 7 intensity levels. Walk away from the toy with the remote to demo its 5 meter working range.
4. Point out how quiet ROMP Party is as the toy cycles through different intensity levels.
5. Hold the power button on the toy for 3 secs to turn ROMP Party off.
6. Showcase the magnetic charging pins as an extra value to the price point.



Packaging contains



Technical Information

Device Model No.	PAR3C
Remote Model No.	R-PAR2A
Name	ROMP Party
Packaging dimensions	130 x 105 x 60mm
Packaging weight incl. product:	125 grams
Battery type	Li-ion Polymer battery
Case dimensions	54.5 cm x 28cm x 34cm
Case weight	0.9g
Warranty	2 years

COLOR	SKU	EAN
PURPLE	RPTY1SG4	4251460631853